



JASKITLOWR2

Double Shoot Lower Hardware Kit & Installation Instructions

| ITEM NO. | PART NUMBER | DESCRIPTION | QTY. |
|----------|--------------------|-----------------------------------|------|
| 1 | T00063P | 2.25" Latch SS | 2 |
| 2 | SMBC-10-1.5-35-2-3 | M10-1.5mm X 35mm Carriage Bolt SS | 4 |
| 3 | SMBC-10-1.5-25-2-3 | M10-1.5mm X 25mm Carriage Bolt SS | 2 |
| 4 | SMWI-16-030-M-2 | M16 Flat Washer SS | 6 |
| 5 | SMNN-10-1.5-3 | M10-1.5mm Nylon Lock Nut SS | 7 |
| 6 | SMBH-04-0.7-16-2-3 | M4-0.7 X 16mm Hex Bolt SS | 4 |
| 7 | SMNN-04-0.7-3 | M4-0.7 Nylon Lock Nut SS | 4 |
| 8 | SMBC-06-1.0-20-1-3 | M6-1.0 X 20mm Carriage Bolt SS | 10 |
| 9 | SMNF-06-1.0-3 | M6-1.0mm Flange Nut SS | 18 |
| 10 | SMBH-06-1.0-20-2-3 | M6-1.0mm X 20mm Hex Bolt SS | 2 |
| 11 | SMWI-06-012-M-3 | M6 Flat Washer SS | 6 |
| 12 | SMWI-10-020-M-2 | M10 Flat Washer SS | 10 |
| 13 | SMBH-10-1.5-20-2-3 | M10-1.5 X 20mm Hex Bolt SS | 1 |
| 14 | SMBC-06-1.0-45-1-3 | M6-1.0 x 45mm Carriage Bolt SS | 2 |
| 15 | SMBC-06-1.0-60-1-3 | M6-1.0 x 60mm Carriage Bolt SS | 4 |
| 16 | SIAH-014-087-3-1-3 | #14 x 7/8" Sheet Metal Screw SS | 16 |

IMPORTANT: Apply antisieze to all threaded stainless steel surfaces to prevent cold weld!

